



INSTALLATION INSTRUCTIONS FOR CATALOG NUMBERS: ALL ROUND PUFP ROUND COVER THAT START WITH PUFP-B AND PUFP-S.

IMPORTANT: These are installation Instructions for use with PUFP-WB stamped steel floor box. This is for a drop-in wood floor installation. For concrete installation, please see FB Installation Instruction sheet.

IMPORTANT: Read all instructions before installing the ROUND PUFP-SERIES

PRIOR TO INSTALLATION

- Contact a local electrical inspector to make sure that this product meets or exceeds all local electrical codes (electric codes may vary by location).
- Make sure there is adequate space to install (see below: CUT OUT AND MOUNTING STEPS)
- Disconnect and turn off all power sources.

CONDITIONS:

- For indoor use only.
- This product is designed for floor installations only
- Only licensed, insured, and bonded electrical contractors should install the ROUND PUFP series.
- These products have no field serviceable parts. If the product is damaged, it must be returned to the factory. Any attempt to alter this product in any way may cause electrocution.
- Lew Electric accepts no responsibility if the above conditions are not followed

FLOOR INSTALLATIONS:

- Select the desired location of the floor.
- Cut a hole in the floor 4 & 1/16 squared.
- Only use supplied Lew stamped steel box (PUFP-WB)
- Using a router or similar device, route down a depth of 1/4" on the finished floor where both of the installation tabs will be placed for installation.
- Fasten the box with provided wood screws.

MOUNTING THE COVER:

- Drop the cover into the floor or desktop opening and use Phillips head screwdriver with supplied mounting screws.
Fasten completely so that the cover will close when not in use.
- Pull the button to open the lid and expose the receptacle. To close the lid pull the button while simultaneously closing the lid with your other hand.
- PLUG THE CORD INTO AN APPROVED RECEPTACLE.